


WARNING

The information in this quick guide is subject to change due to product updates or other reasons. This guide cannot replace the product labels or the safety precautions in the user manual unless otherwise specified. All descriptions in the manual are for guidance only.




Device	Model	Description
Inverter	GW8000-ES-C10 GW10K-ES-C10 GW12K-ES-C10	<ul style="list-style-type: none"> When only one inverter is used in the system, it is supported to connect generator. When multiple inverters are used in the system, it is not supported to connect generator; a maximum of 16 inverters are supported to form a parallel system, and the Ezlink3000 is required in the parallel system. The complexity of the parallel system increases with the increase of the number of inverters in parallel. When the number of inverters in parallel system is ≥ 6, please contact the after-sales service to confirm the installation and application environment of the inverters to ensure stable operation of the system. <p>Requirements for parallel system:</p> <ul style="list-style-type: none"> The software version of all inverters in the system is the same. The ARM software version of the inverter is 08 (415) and above. The DSP software version of the inverter is 00(2525) and above.

Device	Model	Description
Battery system	LX A5.0-10 LX A5.0-30 LX U5.4-20 LX U5.0-30	<p>Battery of different models cannot be mix used.</p> <ul style="list-style-type: none"> LX A5.0-10: The nominal charging and discharging current of a single battery is 60A; a maximum of 15 batteries can be connected in parallel in one system. LX A5.0-30: The nominal charging current of a single battery is 60A, and the discharging current is 100A; the maximum continuous charging current is 90A; the maximum continuous discharging current is 150A. A maximum of 30 batteries can be connected in parallel in one system. LX U5.4-20: The maximum discharge current of a single battery is 50A; A maximum of 6 batteries can be connected in parallel in one system. LX U5.0-30: The nominal charging current of a single battery is 60A, and the discharging current is 100A; the maximum continuous charging current is 90A; the maximum continuous discharging current is 100A. A maximum of 30 batteries can be connected in parallel in one system.
	Lead-acid Battery	<ul style="list-style-type: none"> Supports connection to lead-acid batteries of AGM, GEL, and Flooded types. The number of batteries that can be connected in series is calculated based on the voltage of lead-acid batteries, and the total voltage of batteries connected in series is not allowed to exceed 60V.
Busbar	BCB-11-WW-0 BCB-22-WW-0 BCB-32-WW-0 BCB-33-WW-0 (Purchase from GoodWe)	<ul style="list-style-type: none"> When the charging and discharging current between battery and inverter is less than 160A, it supports direct connection between battery and inverter without using a busbar. For example: It supports connecting GW8000-ES-C10 to LX A5.0-30 without using a busbar. For detailed battery wiring methods, please refer to 6.6 Connecting the Battery Cable. When the charging and discharging current between battery and inverter is $\geq 160A$, a busbar or busbar box must be used to connect the inverter. (Current $\geq M \times IBat$ rated. (M: The quantity of batteries connected in parallel in the system, IBat rated: The rated current of the battery)). <ul style="list-style-type: none"> BCB-11-WW-0: <ul style="list-style-type: none"> Used with LX A5.0-10, the battery system supports a maximum working current of 360A, working power of 18kW, and can connect to a maximum of 3 inverters, and 6 batteries. BCB-22-WW-0: <ul style="list-style-type: none"> Used with LX A5.0-10, the battery system supports a maximum working current of 720A, working power of 36kW, and can connect to a maximum of 6 inverters, and 12 batteries. Used with LX A5.0-30, the battery system supports a maximum working current of 720A, working power of 36kW, and can connect to a maximum of 6 inverters, and 6 batteries. BCB-32-WW-0: <ul style="list-style-type: none"> Used with LX A5.0-10, the battery system supports a maximum working current of 720A, working power of 36kW, and can connect to a maximum of 6 inverters, and 15 batteries. Used with LX A5.0-30, the battery system supports a maximum working current of 720A, working power of 36kW, and can connect to a maximum of 6 inverters, and 15 batteries. Used with LX U5.0-30, the battery system supports a maximum working current of 720A, working power of 36kW, and can connect to a maximum of 6 inverters, and 8 batteries. BCB-32-WW-0: <ul style="list-style-type: none"> Used with LX U5.0-30, the battery system supports a maximum working current of 720A, working power of 36kW, and can connect to a maximum of 6 inverters, and 15 batteries. Others: Please prepare busbar based on actual system power and current.

Device	Model	Description
Smart Meter	<ul style="list-style-type: none"> Built-in Smart Meter (Standard) GMK110 (optional) GM330 (purchase from GoodWe) 	<ul style="list-style-type: none"> Built-in smart meter: 10-meter wire CT, default CT ratio: 120A/40mA GMK110: When the length of the built-in CT cable of the inverter is not enough for connection to the switchboard, it can be extended through an external GMK110 smart meter. CT is not supported for changing to other type, CT ratio: 120A/40mA CM330: order the CT for GM330 from GoodWe or other suppliers. CT ratio: nA/5A. <ul style="list-style-type: none"> nA: CT primary input current, n ranges from 200 to 5000. 5A: CT Secondary input current.
Smart Dongle	<ul style="list-style-type: none"> WiFi/LAN Kit-20 (Standard) Ezlink3000 (purchase from GoodWe) 	<ul style="list-style-type: none"> Please use the WiFi/LAN Kit-20 module in single inverter system. In parallel system, the EzLink3000 must be connected to the master inverter. Do not connect any smart dongle to slave inverter. Ezlink3000 requires a firmware version of 04 or above.


02 Power On/Off

Single inverter system



Multi-inverter system

Only for inverter without LCD screen




03 Installations

Steps	1 Installation	2 PE	3 PV	4 Battery	5 AC	6 COM	7 Communication module	
Inverter							WiFi/LAN Kit-20 	Ezlink3000
Tools	1 D: 80mm φ: 8mm 2 M5 \oplus 1.5-2N·m 	M5 \oplus 1.5-2N·m 	Recommend: PV-CZM-61100 	1 M10 \oplus 3.9-4.1N·m 2 M4 \oplus 0.8N·m 	M5 \oplus 1.9-2.1N·m 			

Steps	1 Installation				2 PE	3 Battery	4 COM			
Battery	LX A5.0-10 	LX A5.0-30 	LX U5.4-20 	LXU 5.0-30 	LX A5.0-10/LX A5.0-30 LX U5.4-20 LXU 5.0-30 	LX A5.0-10 LX A5.0-30 LXU 5.0-30 	LX A5.0-10 LX A5.0-30 LXU 5.0-30 	LX U5.4-20 		
Tools										
	M4 \oplus 1.4N·m 	M6 \oplus 6N·m 	M4 \oplus 1.4N·m 	M6 \oplus 6N·m 	1 M6 \oplus 6N·m 2 M4 \oplus 1.4N·m 3	1a D: 80mm φ: 8mm 1b D: 65mm φ: 13mm 2a ST5.5 \oplus 10N·m *70 2b M10 \oplus 10N·m 1 3 M5 \oplus 2N·m 3 M5 \oplus 4N·m 	1 M5 \oplus 4N·m 2 M5 \oplus 2N·m 3 M5 \oplus 4N·m 	1 M6 \oplus 6N·m 2 M8 \oplus 12N·m 	Recommend: YQK-70 	


Steps	1 Installation	2 Cable Connections	3 Power	4 Commissioning
Smart meter	GMK110 	GM330 	GMK110 	GM330
			AC breaker 	QR code → SolarGo APP QR code → SEMS Portal APP or SEMS Portal WEB
		0.3-0.5N·m 		1.2-2N·m

04 Wiring Diagram ES Uniq 8-12kW (single) + Lynx Home A or U or Lead-acid battery + Built-in smart meter + WiFi/LAN Kit-20




Busbar	S
BCB-32-WW-0	LX A5.0-30: 50mm ²
BCB-22-WW-0	LX A5.0-30: 25mm ²
BCB-22-WW-0	LX A5.0-30: 25mm ²
BCB-22-WW-0	LX A5.0-30: 25mm ²


ES Uniq 8-12kW (single) + Lynx Home A or U or Lead-acid battery + GMK110 + WiFi-LAN Kit-20



ES Uniq 8-12kW (parallel connected) + Lynx Home A or Lead-acid battery + GM330 + Ezlink3000



Battery System Wiring Diagram



The wiring methods are the same when using third-party busbars for LX A5.0-10 and LX A5.0-30, taking LX A5.0-10 as an example here.

The quantity of batteries depends on the required voltage.

05 Equipment Commissioning



In parallel scenarios, the software version of SolarGo app should be 5.4.0 or above.
Follow the prompts to connect the device.


Quick Settings

Method I: Tap **Home** > **Settings** > **Quick Settings** to complete quick settings step by step.

Installer password: goodwe2010


Method II: Using LCD screen to finish quick settings. Click on the screen or use buttons to operate.

> **Quick Setting**, follow the prompts to complete inverter settings.




Setting Safety Code


Setting safety code via SolarGo APP




Setting safety code via LCD screen



Setting Inverter Quantity (Only For Parallel Connections, APP only)




Setting the BAT Connect Mode via SolarGo APP




Setting BAT parameter via LCD screen


Lithium battery (GOODWE battery)




Lithium battery (Models not in the list)



Lithium battery (Models in the list)



Lead-acid battery



Setting working mode via LCD screen

Back-up Mode

Step 1: Quick Setting menu. Working Mode is selected.

Step 2: Working Mode selection screen. Self-use and Back-up Mode are checked.

Step 3: Next button.

Step 4: Back-up Mode configuration screen. Charging From Grid is ON. Rated Power is 0.00%.

TOU Mode

Step 1: Quick Setting menu. Working Mode is selected.

Step 2: Working Mode selection screen. Self-use and TOU Mode are checked.

Step 3: Next button.

Step 4: Back-up Mode configuration screen. Charging From Grid is ON.

Step 5: Confirm button.

Step 6: TOU Mode configuration table:

Charge	Discharge	Time	Power(%)	Bat(%)
<input checked="" type="checkbox"/>	<input type="checkbox"/>	00:00 - 00:00	0.00	0.00
<input checked="" type="checkbox"/>	<input type="checkbox"/>	00:00 - 00:00	0.00	0.00
<input type="checkbox"/>	<input type="checkbox"/>	00:00 - 00:00	0.00	0.00
<input type="checkbox"/>	<input type="checkbox"/>	00:00 - 00:00	0.00	0.00

Setting working mode via SolarGo APP

Self-use Mode: Depth Of Discharge (On-Grid) 60%, (Off-Grid) 60%.

Peakshaving: Start Time 00:00, End Time 00:00, Import Power Limit 0.00.

Advanced Settings: Back-up Mode selected.

Depth Of Discharge (On-Grid):
The maximum depth of discharge of the battery when the system is working on-grid.

Depth Of Discharge (Off-Grid):
The maximum depth of discharge of the battery when the system is working off-grid.

BACK-UP Mode: Charging From Grid ON, Rated Power 0.0. Grid charge: Open. Backup SOC: 60%.

TOU Mode: Economic Mode. Battery Working Mode Group1 (00:00-07:00) and Group2 (08:00-16:00). PV: Charge battery in priority.

Smart Charging Mode: Smart Charging Month. Peak Limiting Power 0.0. Switch To Charge ON. PV switches from selling electricity to charging batteries.


TOU Curves: Shows PV curve, Power export, Load curve, Charge, and Discharge for different modes.

PV Curves: Shows Power export, Charge, and Load consumption for different modes.

Setting the Advanced Parameters

Tap **Home > Settings > Advanced Settings** to set the following functions.

Setting DRED/Remote Shutdown/RCR



This function is disabled by default. To use the Remote Shutdown function, turn on this switch.


Setting Battery Functions




Through battery function settings, you can set parameters for battery connected in the system.

Setting Power Limit

Tap **Home > Settings > Advanced Settings** to set the following functions.





Setting power limit via LCD screen



Configuring the Network


Tap **Home > Settings > Communication Setting** to set network parameters.

WiFi/LAN Kit-20




Setting GEN port

Tap **Home > Settings > Quick Settings** to set parameters for generator or load.



Creating a Power Plant

Create power plants and add equipments via SEMS Portal app.



Settings generator parameters via LCD screen

