

This document lists the compatible batteries with GoodWe storage inverters, consisting in 4 system types:

- 1) Low-voltage energy storage systems
- 2) High-voltage energy storage systems
- 3) Commercial and industrial energy storage systems (for U.S only).
  4) High-voltage Energy Storage Systems (for U.S only).

Only batteries listed in this document are approved for connection to GoodWe storage inverters according to GoodWe Limited Warranty.

In addition to the batteries listed in this document, there are some batteries that follow the GOODWE CAN communication protocol that are not listed in this document, if you need to get the matching information for these batteries, please consult GOODWE's technical service personnel.

## 1) Low-voltage Energy Storage Systems

Battery	Battery	Battery	Battery Inverter Series									
Brand	Series	Model	ES	EM	SBP	ES G2	SBP G2	ES uniq (8 ~ 12K)	ES Uniq (3 ~ 6K)	EO	ET LV	
	SECU-A	SECU-A5.4L	•		•	•	•					
		LX U5.4-L*1	•	•	•		•	•				
	Lynx Home U	LX U5.4-20*2						•				
GOODWE	-	LX U5.0-30*4						•	•			
	Lyny Homo A	LX A5.0-10 <sup>*3</sup>					•	•	•	•		
	Lynx Home A	LX A5.0-30 <sup>*5</sup>						•	•			
	BAT	GW14.3-BAT-LV-G10*6						•	•			

- BAT GW14.3-BAT-LV-G10<sup>16</sup>

  \*1. ARM firmware versions 11 and above are required for compatibility.
  \*2. ARM firmware versions 11 and above are required for compatibility.
  \*4. ARM firmware versions 22 and above are required for compatibility.
  \*4. Lynx Home U-30 model batteries are compatible with ES/EM/SBP/BP series inverters. The BMS version must be ≥01, i.e., batteries manufactured after April 2025.
  ES 62/SBP 62:
  \*2. ARM firmware versions 02 and above are required for compatibility.
  \*3. ARM firmware versions 07 and above are required for compatibility.
  \*4. ARM firmware versions 09 and above are required for compatibility.
  \*5. ARM firmware versions 09 and above are required for compatibility.
  \*5. ARM firmware versions 10 and above are required for compatibility.
  \*6. ARM firmware versions 09 and above are required for compatibility.
  \*6. ARM firmware versions 09 and above are required for compatibility.
  \*6. ARM firmware versions 03 and above are required for compatibility.
  \*6. ARM firmware versions 03 and above are required for compatibility.
  \*6. ARM firmware versions 03 and above are required for compatibility.
  \*6. ARM firmware versions 03 and above are required for compatibility.
  \*7. ARM firmware versions 03 and above are required for compatibility.
  \*6. ARM firmware versions 05 and above are required for compatibility.
  \*6. ARM firmware versions 05 and above are required for compatibility.
  \*6. ARM firmware versions 05 and above are required for compatibility.
  \*6. ARM firmware versions 05 and above are required for compatibility.
  \*6. ARM firmware versions 05 and above are required for compatibility.
  \*6. ARM firmware versions 05 and above are required for compatibility.
  \*6. ARM firmware versions 05 and above are required for compatibility.
  \*6. ARM firmware versions 05 and above are required for compatibility.
  \*6. ARM firmware versions 05 and above are required for compatibility.
  \*6. ARM firmware versions 05 and above are required for compatibility.
  \*6. ARM firmware versions 05 and above are required for compatibili

Battery Brand	Battery Series	Battery Model	ES	EM	SBP	ES G2	SBP G2	ES uniq (8 ~ 12K)	ES Uniq (3 ~ 6K)	EO	ET LV
	Battery-Box Pro Series*1	-					•				
	Battery-Box Res Series*1	-									
	Battery-Box LV Series*2	-									
BYD	Battery-Box Premium LVL*2	LVL 15.4									
	Battery-Box Premium LVS Series*2	-									
	BatteryBox LV5.0*3	LV5.0									
	BattervBox LV5.0+*4	LV5.0+									

- ES/EM/SBP/BP:

  \*1. ARM firmware versions 00 and above are required for compatibility.

  ES G2/SBP G2:

  \*3. ARM firmware versions 09 and above are required for compatibility.

  4. ARM firmware versions 09 and above are required for compatibility.

  5. Suning 8~12kW:

  \*3. ARM firmware versions 10 and above are required for compatibility.

  \*4. ARM firmware versions 10 and above are required for compatibility.

  \*4. ARM firmware versions 10 and above are required for compatibility.

Battery Brand	Battery Series	Battery Model	ES	EM	SBP	ES G2	SBP G2	ES uniq (8 ~ 12K)	ES Uniq (3 ~ 6K)	EO	ET LV
		RESU 3.3*1									
		RESU 6.5*1		•			•				
LG	RESU LV Series	RESU 10*1	•	•							
LG	RESU LV Selles	RESU 12*2									
		RESU 13*2									
		RESU 6.4 EX*1	•	•	•						

## ES/EM/SBP:

- 1. ARM firmware versions 00 and above are required for compatibility.
- \*2. ARM firmware versions 07 and above are required for compatibility.

<b>Battery Brand</b>	Battery Series	Battery Model	ES	EM	SBP	ES G2	SBP G2	ES uniq (8 ~ 12K)	ES Uniq (3 ~ 6K)	EO	ET LV
	US2000 Series*1	US2000									
	US3000 Series*2	US3000									
	US2000C Series*1	US2000C									
PYLON	US3000C Series*2	US3000C									
	Force L1 Series*2	Force-L1	•	•		•	•				
	Force L2 Series*2	Force-L2									
	US5000 Series*3	US5000									

- ES/EM/SBP/BP:

  \*1. ARM firmware versions 00 and above are required for compatibility.

  \*2. ARM firmware versions 07 and above are required for compatibility.

  \*3. ARM firmware versions 00 and above are required for compatibility.



## 1) Low-voltage Energy Storage Systems

Battery	Battery	Battery			Inverte	r Series		
Brand	Series	Model	ES	EM	SBP	ES G2	SBP G2	ES Uniq
		DYNESS-LV x1	•	•	•			
	DYNESS-LV Series <sup>*1</sup>	DYNESS-LV x2	•	•	•			
	Diness-Ly selles	DYNESS-LV x3	•	•	•			
		DYNESS-LV x4	•	•	•			
		POWERBOX F-2.5	•	•	•			
	POWERBOX F Series*1	POWERBOX F-5.0	•	•	•			
DYNESS	POWERBOX F Selles	POWERBOX F-7.5	•	•	•			
		POWERBOX F-10.0	•	•	•			
		DL5.0C*2				•	•	•
	DYNESS-LV Series	DL5.0X*3				•	•	
		A48100*4				•	•	
	POWER BOX G2°5	POWER BOX G2				•	•	•
	POWER BRICK*6	POWER BRICK				•	•	•

## ES/EM/SBP/BP:

- \*1. ARM firmware versions 07 and above are required for compatibility.
- \*2. ARM firmware versions 06 and above are required for compatibility.
  \*3. ARM firmware versions 07 and above are required for compatibility.
- \*4. ARM firmware versions 07 and above are required for compatibility.
- \*5. ARM firmware versions 08 and above are required for compatibility.
  \*6. ARM firmware versions 08 and above are required for compatibility.
- ES Uniq:
  \*5. ARM firmware versions 09 and above are required for compatibility.
  \*6. ARM firmware versions 09 and above are required for compatibility.

Battery Brand	Battery Series	Battery Model	ES	EM	SBP	ES G2	SBP G2	ES Uniq
	LBS051100A Series <sup>*1</sup>	LBS051100A-A02						
OLOID	LBS051100A Series	LBS051100A-A03						
OLOID	LBS051200A Series*1	LBS051200A-A02						
	LB3031200A Series	LBS051200A-A03						

\*1. ARM firmware versions 12 and above are required for compatibility.

	•							
Battery Brand	Battery Series	Battery Model	ES	EM	SBP	ES G2	SBP G2	ES Uniq
		Soluna 4K Pack	•	•	•			
Soluna	LV (48V) Battery Series	Soluna 5K Pack		•	•			
		Soluna EOS 5K Pack	•	•	•			
Battery Brand	Battery Series	Battery Model	ES	EM	SBP	ES G2	SBP G2	ES Uniq
	Smile5-BAT Series	SMILE5-BAT*2	•	•	•			
		Smile-BAT-10.1P*2	•	•	•			
ALPHA*1	Smile-BAT Series	Smile-BAT-10.3P*2	•	•	•			
ALPHA		Smile-BAT-13.3P*3	•	•	•			
	M48112-P Series	M48112-P*3	•	•	•			
	M48100-P Series	M48100-P*3	•	•	•			

## ES/EM/SBP/BP:

- \*1. CAN communication line sequence of ALPHA-ESS battery does not match GoodWe inverters. A matching solution provided by ALPHA-ESS is required.
- \*2. ARM firmware versions 10 and above are required for compatibility.
- \*3. ARM firmware versions 11 and above are required for compatibility.

<b>Battery Brand</b>	Battery Series	Battery Model	ES	EM	SBP	ES G2	SBP G2	ES Uniq
		Firefly-3.6K	•	•	•			
		Firefly-7.2K	•	•	•			
		Firefly-10.8K	•	•	•			
Tecloman	Firefly Series <sup>*1</sup>	Firefly-14.4K	•	•	•			
		Firefly-18.0K	•	•				
		Firefly-21.6K	•	•				
		Firefly-25.2K	•	•	•			

## ES/EM/SBP:

\*1. ARM firmware versions 12 and above are required for compatibility.

<b>Battery Brand</b>	Battery Series	Battery Model	ES	EM	SBP	ES G2	SBP G2	ES Uniq
UZENERGY	L051100-A Series	L051100-A <sup>*1</sup>	•	•	•			

## ES/EM/SBP:

\*1. ARM firmware versions 12 and above are required for compatibility.



# 2) High-voltage Energy Storage Systems

Battery	Battery	Battery	Inverter Series ET (5-10kW)* EH** BT BH EHB ET (15-30kW) ET G2 ET (40~50kW) ET (75-10								
Brand	Series	Model	ET (5-10kW)*	EH**	ВТ	BH	EHB	ET (15-30kW)	ET G2	ET (40~50kW)	ET (75-100K)
		LX F6.6-H	•	•	•	•	•	•	•		
	Lynx Home F <sup>*1</sup>	LX F9.8-H	•	•	•	•	•	•	•		
	Lynx Home F PLUS+*2	LX F13.1-H	•	•	•	•	•	•	•		
		LX F16.4-H	•		•			•	•		
		LX F6.4-H-20 <sup>*7</sup>		•		•		•			
		LX F9.6-H-20	•	•	•	•	•	•	•		
		LX F12.8-H-20	•	•	•	•	•	•	•		
	Lynx Home F G2*3	LX F16.0-H-20	•	•	•	•	•	•	•		
	Lynx Home F G2	LX F19.2-H-20	•	•	•	•	•	•	•		
		LX F22.4-H-20 <sup>*8</sup>	•		•		•	•	•		
		LX F25.6-H-20	•		•			•	•		
		LX F28.8-H-20						•	•		
		GW60KWH-D-10						•			
GOODWE		GW100KWH-D-10								•	
		GW100KWH-D-10 (Extension)								•	
	Lynx C <sup>*4</sup>	LX C101-10								•	
		LX C120-10								•	
		LX C138-10								•	
		LX C156-10								•	
	Lynx Home D*5	LXD5.0-10	•	•	•	•		•	•		
		GW51.2-BAT-I-G10								•	•
		GW56.3-BAT-I-G10								•	•
	D A T*6	GW61.4-BAT-AC-G10						•		•	
	BAT*6	GW92.1-BAT-AC-G10						•		•	•
		GW102.4-BAT-AC-G10						•		•	•
		GW112.6-BAT-AC-G10						•		•	•

<sup>\*.</sup> Including ET Series: ET PLUS+, ET PLUS+ (16A)
\*\*.Including EH Series :EH PLUS
ET/EH/BT/BH/EHB:

- \*1. ARM firmware versions 19 and above are required for compatibility.
  \*2. ARM firmware versions 23 and above are required for compatibility.
  \*3. For compatibility, the ET/BT series requires ARM25 and DSP09 versions and above; the EHB series requires ARM25 and DSP version 03 and above; the EH/BH series requires ARM25 and DSP version 07 and above.

  \*5. For compatibility, the ET/BT series requires ARM28 and DSP version 12 and above.

  \*5. For compatibility, the EH/BH series requires ARM29 and DSP version 08 and above.

  ET (15-30kW)/ET G2/ET(40~50kW):

- \*3. For compatibility, the ET (15~30kW) Series requires ARM07 and DSP version 06 and above.

  \*4. For compatibility, the ET (15~30kW) series requires ARM07 and above.

  \*4. ET 50kW with Lynx C-Series LX C101-10, LX C120-10 cannot reach the maximum power of the inverter.

- \*4. ET 50kW with Lynx C-Series LX C101-10, LX C120-10 cannot reach the maximum power of the inverter.
  \*5. For compatibility, the ET(15~30kW) series requires ARM 09 and DSP version 08 and above.
  \*3. ET (15~30kW) matching Lynx Home F G2 Series LX F9.6-H-20 requires ARM09 and DSP08 and above.
  \*7. Lynx Home F G2 Series LX F6.4-H-20 only supports GW12KL-ET and GW18KL-ET models in the ET (15~30kW) series.
  \*6. For compatibility, the ET (40~50k) series requires ARM10 and above.
  \*6. For compatibility, the ET (15~30k) series requires ARM13 and above.
  \*6. The BAT series GW61.4-BAT-AC-G10 model paired with ET (40~50kW) cannot achieve full power output from the inverter.
  \*8. The EHB series requires firmware version ARM32/DSP 02 or higher to be compatible with the LX F22.4-H-20 model.



## 2) High-voltage Energy Storage Systems

Battery	Battery	Battery	Inverter Series								
Brand	Series	Model	ET (5-10kW)*	EH**	ВТ	ВН	EHB	ET (15-30kW)	ET G2	ET (40~50kW)	
	Battery-Box HV Series*1	-	•	•	•						
		HVM 8.3		•		•	•				
		HVM 11.0	•	•	•		•	•	•		
	Battery-Box Premium	HVM 13.8	•	•	•		•	•	•		
	HVM*2	HVM 16.6	•	•	•		•	•	•		
		HVM 19.3	•	•	•		•	•	•		
		HVM 22.1	•	•	•	•	•	•	•		
		HVS 5.1	•	•	•	•	•	•	•		
	Battery-Box Premium	HVS 7.7	•	•	•	•	•	•	•		
	HVS*2	HVS 10.2	•	•	•	•	•	•	•		
		HVS 12.8	•		•			•	•		
		HVM+ 11.0						•	•		
BYD		HVM+ 13.8						•	•		
טוט	Battery-Box HVM+	HVM+ 16.6						•	•		
		HVM+ 19.3						•	•		
		HVM+ 22.1						•	•		
		HVS+ 5.1						•	•		
	Datter David NC	HVS+ 7.7						•	•		
	Battery-Box HVS+	HVS+ 10.2						•	•		
		HVS+ 12.8						•	•		
		LITE 30								•	
		LITE 37.5								•	
	DATTEDVAAAV LITE*3	LITE 45								•	
	BATTERYMAX LITE <sup>-3</sup>	LITE 52.5								•	
		LITE 60								•	
		LITE 67.5								•	

- \*. Including ET Series: ET PLUS+, ET PLUS+ (16A) \*\*.Including EH Series :EH PLUS ET/EH/BT/BH/EHB:

- \*1. ARM firmware versions 07 and above are required for compatibility.
  \*2. ARM firmware versions 11 and above are required for compatibility.

## ET15~30kW:

- \*2. ARM firmware versions 02 and above are required for compatibility.

  BYD CAN communication line PIN1/2 corresponds to inverter CAN communication line PIN4/5.

  \*2. The maximum charge/discharge current of single-cluster HVS battery is 25A, ET30kW with single-cluster HVS battery will not be able to reach the nominal maximum charge/discharge power of the inverter. ET15~30 series with HVM battery maximum charging and discharging current of 40A.

  \*2. BYD HVM 11.0 is used with ET15~30kW inverters, inverter version must be ARM 09/DSP08 or above.

ET 40~50kW:
\*3. ARM firmware versions 08 and above are required for compatibility.

Battery Brand	<b>Battery Series</b>	Battery Model	ET (5-10K)*	EH**	ВТ	ВН	EHB	ET (15-30K)	ET G2	ET (40~50K)
		FLEX 8.6								
	RESU FLEX Series*1	FLEX 12.9								
LG		FLEX 17.2								
LG	RESU Type-R Series	RESU10H_Type-R					•			
	RESU Prime Series <sup>2</sup>	RESU10H Prime					•			
	RESU Plille Selles	RESU16H Prime								

<sup>\*\*.</sup>Including EH Series :EH PLUS EH/BH/EHB:

- \*1. Only compatible with ET PLUS+ Series. ARM firmware versions 23 and above are required for compatibility.
  \*2. ARM firmware versions 20 and above and DSP versions 02 and above are required for compatibility.

<b>Battery Brand</b>	<b>Battery Series</b>	Battery Model	ET (5-10K)*	EH**	BT	ВН	EHB	ET (15-30K)	ET G2	ET (40~50K)
	Powercube H1 Series*1	POWERCUBE-H1-48		•	•					
PYLON	Force H1 Series*2	Force-H1		•	•	•			•	
PILON	Force H2 Series	Force-H2		•	•	•			•	
	Force H3 Series <sup>*3</sup>	Force-H3		•	•	•			•	

<sup>\*\*.</sup>Including EH Series :EH PLUS

## EH/BH/BT:

\*\*1. ARM firmware versions 07 and above are required for compatibility. Please note that the nominal voltage of POWERCUBE-H1-48 Series must be within the Battery Voltage Range of GoodWe inverters. Maximum 8 units for EH/BH.

\*\*2. ARM firmware versions 14 and above are required for compatibility.

\*\*3. ARM firmware versions 14 and above are required for compatibility.

\*\*3. ARM firmware versions 14 and above are required for compatibility. Please note that the nominal voltage of Force H3 Series must be within the Battery Voltage Range of GoodWe inverters. Maximum 4 units for EH/BH.

ET G2:
\*3. Please note that the nominal voltage of Force H3 Series must be within the Battery Voltage Range of GoodWe inverters. Maximum 6 units for ET G2.



# 2) High-voltage Energy Storage Systems

Battery	Battery	Battery			Inv	erter Se	ries	
Brand	Series	Model	EH**	вт	вн	EHB	ET (15~30kW)	ET G2
		Tower T7	•		•			•
		Tower T10	•	•	•		•	•
	Tower Series*1	Tower T14	•	•	•		•	•
		Tower T17		•			•	•
		Tower T21					•	•
DYNESS		Tower Pro TP7						•
		Tower Pro TP11		•			•	•
	Tower Pro Series*2	Tower Pro TP15		•			•	•
		Tower Pro TP19		•			•	•
		Tower Pro TP23					•	•
	STACK100*3	STACK100					•	

<sup>\*\*.</sup>Including EH Series :EH PLUS EH/BH/BT:

- \*1. ARM firmware versions 10 and above are required for compatibility.
  \*2. ARM firmware versions 10 and above are required for compatibility.

- \*1. ARM firmware versions 13 and above are required for compatibility.
  \*2. ARM firmware versions 13 and above are required for compatibility.

- 2. ARM firmware versions 15 and above are required for compatibility.

  \*1. ARM firmware versions 08 and above are required for compatibility.

  \*2. ARM firmware versions 08 and above are required for compatibility.

  \*3. ARM firmware versions 08 and above are required for compatibility.

  Note that ET15~30K only supports 5~13 modules of STACK100 batteries, the inverter will be damaged if the number of batteries does not match.

<b>Battery Brand</b>	Battery Series	Battery Model	EH**	ВТ	ВН	EHB	ET (15~30kW)	ET G2
	Soluna HV Battery Series <sup>⁺1</sup>	Soluna 7K Pack HV	•		•			
Soluna		Soluna 10K Pack HV	•	•	•			
		Soluna 15K Pack HV		•				

<sup>\*\*.</sup>Including EH Series :EH PLUS

EH/BH/EHB/BT:
\*1. ARM firmware versions 10 and above are required for compatibility.

<b>Battery Brand</b>	<b>Battery Series</b>	Battery Model	EH**	BT	ВН	EHB	ET (15~30kW)	ET G2
iPotisEdae Mint-JKE*1	Mint-JKE5	•		•				
	Mint-JKE10	•		•				
iPotisEdge	WIIII-JNE	Mint-JKE15	•	•	•			
		Mint-JKE20	•	•	•			

<sup>\*\*.</sup>Including EH Series :EH PLUS

# 3) Commercial and Industrial Energy Storage Systems

Battary Brand	Battery Series	Pottory Model	Inverter Series			
Battery Brand	Dattery Series	Battery Model	ETC	BTC		
	Lynx C series <sup>*1</sup>	LX C 101-10	•	•		
GOODWE		LX C 120-10	•	•		
GOODWE		LX C 138-10	•	•		
		LX C 156-10	•	•		

EH/BH/EHB/BT:
\*1. ARM firmware versions 12 and above are required for compatibility.

ETC 50kW/BTC 50kW:
\*1: EMS firmware versions 02 and above are required for compatibility.

<sup>\*1.</sup> EMS firmware versions 00 and above are required for compatibility.



# 4) High-voltage Energy Storage Systems (for U.S only).

Pottory Prond	Battery Series	Pottory Model	Inverter Series					
Battery Brand		Battery Model	A-ES	A-BP	ES-US20	SBP-US20		
		SECU-S13	•	•				
	SECU-S <sup>*1</sup>	SECU-S15	•	•				
		SECU-S18	•	•				
GoodWe		SECU-S20	•	•				
Goodyve		LX F9.6-30	•	•	•	•		
	Lynx Home FH series US <sup>*2</sup>	LX F12.8-30	•	•	•	•		
	Lynx nome an series US	LX F16.0-30	•	•	•	•		
		LX F19.2-30	•	•	•	•		

### A-ES/A-BP:

- 1. ARM firmware versions 14 and above are required for compatibility. ES-US20/SBP-US20:
- \*2. ARM firmware versions 03 and above are required for compatibility.

A-ES/A-BP:
\*2. ARM firmware versions 24 and above and DSP versions 07 and above are required for compatibility.

Battery Brand	Battery Series	Battery Model	A-ES	A-BP	ES-US20	SBP-US20
		HVL 12.0	•	•		
		HVL 16.0	•	•		
BYD	Battery-Box Premium HVL <sup>*1</sup>	HVL 20.0	•	•		
ыб		HVL 24.0	•	•		
		HVL 28.0	•	•		
		HVL 32.0	•	•		

## A-ES/A-BP:

\*1. ARM firmware versions 11 and above are required for compatibility.

Battery Brand	Battery Series	Battery Model	A-ES	A-BP	ES-US20	SBP-US20
	LBS102100A Series*1	LBS102100A	•	•		
OLOID	LBS153100A Series*1	LBS153100A	•	•		
	LBS205100A Series*1	LBS205100A	•	•		

A-ES/A-BP:
\*1. ARM firmware versions 14 and above are required for compatibility.

Battery Brand	Battery Series	Battery Model	A-ES	A-BP	ES-US20	SBP-US20
	Soluna 7K Pack HV	•	•	•	•	
Soluna	HV Battery Series*1*2	Soluna 10K Pack HV	•	•	•	•
		Soluna 15K Pack HV	•	•	•	•

- A-ES/A-BP:
  \*1. ARM firmware versions 10 and above are required for compatibility.
- Soluna HV does not have UL9540 certificate.

## ES-US20/SBP-US20

- 1. ARM firmware versions 07 and above are required for compatibility.
- \*2. Soluna HV does not have UL9540 certificate.

Battery Brand	Battery Series	Battery Model	A-ES	A-BP	ES-US20	SBP-US20
LG	RESU Type-R Series*2*3	RESU10H_Type-R	•	•		
	RESU Prime Series*1*4	RESU10H Prime	•	•	•	•
	RESO FIIIIle Selles	RESU16H Prime	•	•	•	•

- A-ES/A-BP:
  \*1. ARM firmware versions 20 and above and DSP versions 05 and above are required for compatibility.

- \*1. ARM firmware versions 20 and above and DSP versions to and above are required for companying.

  \*2. When A-BP is compatible with LG RESU HV Series, the micro-grid applications are not supported.

  \*3. The compatibility of A-ES/A-BP with LG RESU10H Type-R is stated as follows:

  1) Connection of RESU10H Type-R batteries in parallel is not supported.

  2) For first inverter operation with LG battery, the inverter must be powered by the grid for the LG battery to be activated.

  3) LG RESU10H Type-R battery Max discharge power is 5kW. Please ensure backup load peak power does not exceed 5kVA in backup mode. Loads with large inrush current for the total control of the total con
- 3) LG RESUTUR Type-R battery what discharge power is skw. Please ensure backup load peak power does not exceed skw in backup mode. Loads with large inrush current (such as inductive loads including motors) may lead to output failure on backup side.

  4) Depending on real-time battery condition, such as SOC, battery temperature etc, the battery output power may not be able to support backup load, which could lead to system failure. If this occurs, both battery and backup supply will cease. Power will resume if there is solar power available.

  5) LG battery needs time to switch from charge to discharge up to the preset power. Quickly switching from on-grid mode to backup mode could fail if backup load power is higher than the max power ramp-up the battery can sustain within a limited time.

  \*4. ARM firmware versions 05 and above and DSP versions 02 and above are required for compatibility.